



7001500016 Insert for a T600 16 mm Car Frame Guide Shoe

Kod produktu: 7001500016



7001500016 Guide shoe insert for a T600 16 mm guide shoe for a car frame