



Actuators for all applications

Actuators for AZ 05x, 05




AZ 05 B (Standard)




AZ 05 B-1684


Actuators for AZ 06x, 06, 07, 08, 13, 14-1, 19




AZ 06-13 B/18, 21, 23




AZ 07-14 B/18, 21, 23




AZ 06 B-1284



Spez. 2006-2, 2006-3



Spez. 1949-1 with alignment tool



Spez. 2006, 2006-1

Ordering data

Actuator
Actuator

AZ 05 B
AZ 05 B-1684

Actuator, length 18 mm
Actuator, length 21 mm
Actuator, length 23 mm
Actuator for hook bars

AZ 06-13 B/18
AZ 06-13 B/21
AZ 06-13 B/23
AZ 06 B-1284

Ordering data

Actuator, length 18 mm
Actuator, length 21 mm
Actuator, length 23 mm

AZ 07-14 B/18
AZ 07-14 B/21
AZ 07-14 B/23

Length X=12 mm, Y=5 mm
Length X=15 mm, Y=5 mm
Length X=12 mm, Y=7 mm
Length X=15 mm, Y=10 mm

Spez 2006
Spez 2006-1
Spez 2006-2
Spez 2006-3